


6.02 Lecture 5 - ISI and Noise

- Inter-Symbol Interference + Noise
 - Eye diagrams help us understand:
 - BER versus Samples per bit ($1/(\text{bit rate})$)
- Calculating BER from Eye Diagram
 - By picture in lecture, details in recitation
- Noise and Deconvolution
 - Massaging the Unit Sample response.

Block Diagram of the Channel



X : transmitted samples


Y_{nf} : received noise-free samples

N : noise samples


Y : received samples with added noise

Unit Sample Response and Eye Diagrams (35 Samples per bit)


Unit Sample Response



Receiver_data




Eye diagram for channel 1




Bit detection Sample


Plots of PDF's of Noise + Detection V's




Unit Sample Response for a Simple Example




Eye Diagram for 3 samples per bit




Eye Diagram for 4 Samples per bit




Eye Diagram for 5 Samples per bit




Eye Diagram for 6 Samples per bit




Eye Diagram For 7 Samples per bit




BER Versus Samples per Bit (std = 0.1)




BER Versus Samples per Bit (std = 0.3)




Unit Sample Response for a Real Example




Eye Diagram for 2 samples per bit




Eye Diagram for 3 Samples per bit




Eye Diagram for 4 Samples per bit




Eye Diagram for 13 Samples per bit




BER Versus Samples per Bit (std = 0.1)



BER Versus Samples per Bit (std = 0.3)



Block Diagram of Channel with Deconvolver



X : transmitted samples


Y_{nf} : received noise-free samples

N : noise samples

Y : received samples with added noise

W : processed received samples

LTI Channel + Noise + Deconvolver





$$y_{nf}[n] = \sum_{m=0}^{m=n} h[m]x[n-m]$$


$$y[n] = y_{nf}[n] + noise[n]$$

$$\sum_{m=0}^{m=n} h[m]w[n-m] = y[n]$$

Slow Wire and 20 Samples per bit




Deconvolution Great Unless There's Noise



- Can we fix deconvolution when there's Noise?


And why study deconvolution?

- High Speed channels use Decision Feedback Equalization (a form of deconvolution).
- Many applications in biology, aerospace, medical imaging, etc



http://www.mib.ac.uk/research/facilities/bionano/Copy%20of%20bionano%20Delta_clip_image002.jpg


Deltavision 3D fluorescence microscopy of a diving *S. pombe* cell. Before deconvolution (Left) and after deconvolution (Right).



<http://www.3d-doctor.com/hubblet.jpg>

Deconvolution of an image from Hubble Space Telescope

We can "Fix" Deconvolution



"Fixed" Deconvolution on IR Channel

